

Operating Instructions

Water Meter for level measurements Type 010 / Triangle frame



ENGLISH

Initial delivery

First supplies generally contain the following items:

- | | |
|-----|---|
| 1 x | Water Meters type 010 |
| 4 x | 4 baby cell batteries (size C) / already integrated in the instrument |
| 1 x | Operating instructions |

If there are items missing, please check the contents of the box again or other packaging, also by verifying the delivery note.

Warranty

The Water Meter type 010 is subject to a warranty period of 2 years from delivery date.

The warranty comprises all defects due to our fault, e.g. construction errors, material defects;

Consequential damages of any kind are excluded from the warranty. Warranty claims against us can only be demanded by our direct party to the contract and cannot be ceded. Special agreements concerning the warranty must be in writing. Verbal agreements cannot be accepted.

Safety instructions



- Do **not** use the Water Meter in a potentially explosive environment. The instrument is not ATEX certified.
- Take care to avoid contamination of groundwater when using the Water Meter. To be certain clean the instrument before using.
- Do not buckle the measuring tape; There is a danger of damaging the instrument.

Document

This document contains information which is protected by copyright. No part of this document may be photocopied or reproduced without the written consent of HT Hydrotechnik GmbH.

Copyright © 2008 by HT Hydrotechnik GmbH. All rights reserved.

Contents

Initial delivery 2

Warranty 2

Safety instructions 2

Document 2

Component description 4

Preparing for operation 5

How to take a measurement 5

Bottom sensor assembling and measuring 6

Cleaning after use 7

Changing the batteries 8

Accessories 9


Replacement parts 9

Factory repair service 10


EC- declaration of conformity..... 11

Epilogue

Component description



Sensor



Preparing for operation

There is no special work to do before putting the instrument into operation. The batteries are already inside the instrument and a complete check up of the Water Meter was done before shipping. If the instrument is to be put into storage for a long time, HT recommends removing the batteries to avoid the risk of damage due to leaking batteries; even with high quality batteries.

The instrument itself will switch on for use and switch off after operation automatically.

How to take a measurement

Water Level Measurement:

To measure the water level let the sensor down in the borehole by winding the measuring tape with the crank.

When the sensor touches the water level the signal lamp of the front side of the Water Meter turns on. Optionally the instrument has an acoustic signal (beeper), depending on the ordered version.

The beeper works simultaneously with the signal lamp.

By dipping several times to the water level, the exact measurement can be obtained. After exact dipping, the water level can be read directly from the measuring tape.

The scale is the metric system and marked in meters (red), decimetres and centimetres (black).

After the measurement the tape with the sensor can be easily rolled up from the groundwater pipe.



Fig. 1: Measuring

Bottom sensor assembling and measuring

Supplied Components

- 1 x Bottom Sensor, ready for use
- 1 x O- ring- seal

Assembling

- Unscrew the sensor weight (Fig. 3)
- Place the O-ring- seal on the electrode
- Screw on the bottom sensor (Fig. 2)

The instrument is ready for use. For testing the complete functionality, use a bottle of water, test if the signal lamp (optionally also the beeper) turns on when the electrode touches the water and turns off when the sensor is completely on the bottom of the bottle.




Fig. 2: Bottom sensor

Depth sounding by using a bottom sensor

By using the bottom sensor the water level measurement is the same as above. Additionally the depth of the groundwater pipe can be sounded. When the sensor reaches the bottom the signal lamp and/or the beeper turns off. The depth of the borehole can read easily from the measuring tape. Add 10cm for the length of the bottom sensor to the value for ground- soundings; for water level measurements, a calculation is NOT necessary;

The bottom sensor is an accessory which is retrofittable.

Cleaning after use

After using the Water Meter type 010 cleaning, depending on the contamination, is recommended by HT. The different parts to be cleaned are described below:

Cleaning of the sensor:

After measurements in contaminated or saline water a complete cleaning of the sensor is recommended to guarantee further correct function.

- Screw of the probe weight (Fig.3)
- Clean the sensor with soap or any other decontamination liquid, depending on the contamination level; To facilitate the cleaning process a hard brush (non- metallic) can be helpful;
- For hard contamination or limy sediments, the electrode can be cleaned by an emery paper
- For using the instrument in fresh / drinking water, clean the complete sensor with distilled water
- After finishing the cleaning, the probe weight can be screwed on




Fig. 3: Sensor

Cleaning of the tape, drum and frame:

Soap is recommended for cleaning the tape. Depending on the dirt level a brush can be helpful. If you are using the tape in fresh / drinking water after an operation in contaminated or salt water, additional cleaning with distilled water is recommended. The drum of the instrument is protected against spray water IP64. Don't submerge the instrument in water for the cleaning process.

Changing the batteries:

In case of low batteries, the signal lamp is not as bright as usual and if integrated, the volume of the acoustic signal is reduced. Usually you will notice a low battery during longer measurement campaigns or after a longer storage period.

HT recommends checking up the batteries before you are going to take the instrument for longer use to the field.




Fig. 4: Replacement of the batteries

Procedure for battery- replacement

- Unscrew the battery casing cap
- Remove the used batteries
- Insert 4 new baby cell batteries 1.5 Volt (Size C);
Caution: The plus- pole of all batteries needs to have contact to the battery cover. (Fig. 4)
- Screw on the battery casing cap by simultaneous pressing and screwing



DO NOT dispose of batteries in normal waste!
For environmental protection and safety, deposit the batteries in battery- disposal boxes or battery- disposal terminals. Alternatively give the old batteries to a waste disposal company.

Accessories

Item	Order No	Comments
Acoustic signal (beeper)	V010Z00010	Not retrofittable
Bottom Sensor	V010Z00014	Retrofittable
Sensor Ø 10mm	V010Z00031	Not retrofittable
Protection bag 15 to 300m	V010Z00011	Retrofittable
Protection bag 300 to 750m	V010Z00015	Retrofittable

Replacement parts

Item	Order No	Comments
Protection cap (for lamp)	F010.00.00.12	Renewable
Signal lamp (5 Volts)	E020.80.00.001	Renewable
LED – signal lamp	V010Z00009	Renewable– also instead of a lamp
Battery casing cap	F010.01.00.008	Renewable
Sensor for self- assembling incl. casting resin	V010Z00005	Renewable – only by technical personnel
Sensor weight	F025000001	Renewable
Spare measuring tape	V010E0xxxx – length	Renewable – only by technical personnel
Crank- handle	F010.01.00.010	Renewable
Crank excl. crank- handle	F010.01.00.015	Renewable – only by technical personnel
Complete brake	F010.01.02	Renewable – only by technical personnel
Baby cell batteries (1.5 Volts)	E020030001	Renewable

Factory repair service

If you believe that the Water Meter is malfunctioning and repair is required, you can help us to provide you with a quick and unbureaucratic service by following the guidelines below:

- Clean the Water Meter including the measuring tape, especially if it has been used in a toxic or hazardous environment
- Carefully pack the Water Meter type 010 in its original shipping box, if possible.
- Send the package, prepaid, to the address below and include a brief description of the malfunction.

Address:

HT Hydrotechnik GmbH

ATTN.: Servicing

Im Wang 18

87634 Oberguenzburg / Germany



!Caution! Please, accept that we can **NOT** take equipment back for repair or servicing which has been used in radioactive contaminated environmental conditions!

Please help us to protect the health and safety of our employees. Inform us by Telefax or eMail incl. the safety instructions if the instrument has been used in toxic or health risky environmental conditions and wait for our instructions before shipment. Use the Telefax- form below:

Company:

Type 010 Length: _____ **m**

Contact person: _____

Phone no.: _____

eMail: _____

With which danger material / liquid is the instrument contaminated? Please, describe:

Do you have safety instructions for the critical material? ☐ Yes ☐ No

If yes, please add it to this Telefax.

If no, where is information available? (Internet address, Company e.g.)

Please, fill in all questions and fax it to the Telefax no.: **+34 872 080 542**

EC- declaration of conformity

Manufacturer:

HT Hydrotechnik GmbH



Water Meter type 010
selectable from 15m to 1000m

Product:

Length of tape:

Functionalities:

The above described instrument measures the water level in boreholes and groundwater observation pipes. By using the accessory "Bottom Sensor", an additional sounding of the borehole depth is possible.

The above described instrument is an original HT product and is manufactured under the authority of the production manager.

The following conformities to the international standards are guaranteed:

Product design:

- CE- conformity for product- safety according to the European Union guideline 2001/95/EG
- CE- conformity for low- voltage design according to the guideline EN 300386 V1.2.1
- CE- conformity for measuring devices according to the European Union guideline 2004/22/EG

Materials:

- Conformity to the European Union guideline regarding electronic components and circuit boards RoHS 2002 / 95 / EG
- Conformity to the guideline regarding corrosion resistance materials DIN EN ISO / IEC 17025:2005

Accuracy of the tape:

- European Union guideline regarding linear measuring tapes /73/362/EWG – Class II
with the 1. adjusted guideline 78/629/EWG
and the 2. adjusted guideline 85/146/EWG

Issuer:

Managing Director

Place, Date:

Obergünzburg, March 27, 2008

A handwritten signature in blue ink, appearing to read 'Schreck', is written over a horizontal line.

Richard Schreck
Managing Director

Release: July, 2008
Document no.: 010.08.2008

For further information or requirements, please contact:

HT Hydrotechnik GmbH

HT Hydrotechnik reserves the right to make technical improvements without any notice or comments in this document.

Distributor:



Envirotechnics Global Service SL
Calle Pirineus 71- 17460 Celrà · España Tel: +34 872 080 542
Avda. Fuentemar, 20 Nave B-10 Parque Navegando 28.823
Coslada · Madrid · España Tel: + 34 916 780 039
envirotechnics@envirotechnics.com www.envirotechnics.com

